## Repair Process Board

## C. MASKING OPTIONS



Use 3M<sup>™</sup> Interior Protection Products (50588, 80308, 50595) to protect the car interior throughout the repair process.



Use 3MTM Premium Clear masking film (80139/50366) to protect those area of the car not to be sprayed during the repair. One man application and clinging properties speed up masking times.



Use 3MTM Trim Masking Tape (06345/47/48/49) on windscreens and components to provide complete protection from overspray.



Use 3M<sup>™</sup> Soft Edge Masking Foam Tape PLUS (50421) for prevention of hard paint edges.



Use 3MTM Trim Lifting Cord (09529) under rubber mouldings to prevent a hard paint edge forming.



Use 3M<sup>TM</sup> Fine Line Masking Tape 471 in 3mm (06404) and 6mm (06405) for accurate masking and detailing.



Use 3M™ Scotch Masking Tape 2328 in 36mm (50032) for general masking and Scotch™ High Performance Masking Tape 3434 in 19mm (07895) for critical areas to optimise spend on masking tape.

Version

3M MAR 10

